Basic commands

Table 1 below shows the basic commands.

Table 1: Basic commands

Command	Instructions
Disarm the system	Press 1, *code.*
Cancel an accidental alarm	Press *code* or press 1, *code.*
Arm to Level 2 (stay)	Press 2, *code.* If the quick arm feature is on, an access code is not required.
Arm to Level 3 (away)	Press 3, *code.* If the quick arm feature is on, an access code is not required.
Send a police alarm	Press and hold both Police buttons for 2 seconds.
Send an auxiliary alarm	Press and hold both Auxiliary buttons for 2 seconds.
Send a fire alarm	Press and hold both Fire buttons for 2 seconds.
Arm system with no delay	Press 2, *code*, 4 (Level 2), or press 3, *code*, 4 (Level 3). If the quick arm feature is on, an access code is not required.
Arm system for latchkey	Press 2, *code*, 6 (Level 2), or press 3, *code,* 6 (Level 3). If the quick arm feature is on, an access code is not required.
Bypass a sensor	Indirectly: Press 2, *code*, # (Level 2), or press 3, *code*, # (Level 3). Directly: Press #, *code*, *sensor number.* If the quick arm feature is on, an access code is not required.
Arm system silently	Press 5, 2, *code* (Level 2), or 5, 3, *code* (Level 3). If the quick arm feature is on, an access code is not required.
Arm system with exit light off	Press 2, *code*, 0 (Level 2), or 3, *code*, 0 (Level 3). If the quick arm feature is on, an access code is not required.
Turn all lights on/off	Press 0, 0.
Turn specific lights on/off	Press 0, *light number.*
Check the system status	Short status: Press *. Full status: Press *, *.
Turn chime on/off	Press 7, 1.
Turn energy saver on/off	Press 7, 2.
Disable local phone access (phone command only)	Press #, 7, 3 or wait 5 seconds after picking up the phone. Your installer can disable local phone control if desired.
Check alarm memory	Press 7, 6.
Activate output	Press 7, 7, *output number* (1 to 6). This must be set up by the installer.
View event history	Press 8, *code*, 8.